

## User Programmable Combination (Optional)

Your Model 259 Control Station provides you with the convenient feature of changing your personal combination whenever you feel it necessary. It is recommended that you write down your old combination and the new one before you begin.

- My system has this feature.  
 My system does not have this feature.

### Notes About Programming

- Programming must be completed in 60 seconds.
- You may only program while the Control Station is disarmed.
- Do not program the same digit twice in a row.  
Example 4556.
- Do not program the first and the last digit the same.  
Example 4564.
- New combination must be four digits in length.

### Programming Steps

1. Press the BLANK key once.
2. Enter the old combination once.
3. Enter the new four digit combination *twice*.
4. Test the new combination several times.



OFFICE  
333-3233

Security Equipment, Inc.

Alarm Specialists

CENTRAL STATION ASSISTANCE  
333-3667

Radionics, Inc. Salinas, CA

# R A D I O N I C S

## **Omegalarm Model 259 Independent Zone Control User's Guide**

### General Information

Your Model 259 Independent Zone Control is an illuminated arming station that provides you with control over a specified area of your security system. The Model 259 gives you independent control of this area, regardless of whether the rest of your security system is armed or disarmed.

Special features of the Model 259 include protection status display indicators, entry and exit delay time, prewarning buzzer, built-in panic alert, and user programmable combination.

### The Control Station Display

The Control Station has two protection status display indicators: a READY indicator and an ARMED indicator.

**READY** — The green indicator light tells you if you may arm your specified area or not. When the green indicator is lighted, the area is ready to be armed. When the green indicator is *not* lighted, there is a faulted zone in the specified area. Correcting the faulted zone usually means closing a door or a window.

**ARMED** — The red indicator light tells you whether the specified area is armed or not. When the red indicator is lighted, the area is armed. When the red indicator is *not* lighted, then the area is not armed.

## The Keypad

The Control Station has a digital keypad used to enter your personal combination into the security system. It is your personal combination which arms and disarms the specified area.

When entering your combination, the Control Station's buzzer may buzz with each key being touched. This indicates that a zone is faulted.

As you touch the keys on the keypad, the keypad is illuminated for night viewing. The keypad is also illuminated during the entry delay time.

## Arming the Specified Area

1. Ensure that the specified area is secure. The green READY indicator light should be "on."
2. Enter your personal combination. The red ARMED indicator light flashes "on" and "off" to indicate exit delay time (approximately 60 seconds). When the ARMED indicator lights steadily, the specified delay area is armed.

## Disarming the Specified Area

Your specified area is disarmed by entering your personal combination. When the area is armed, you must enter the premises through a designated *entry door* to prevent an *instant* alarm condition. Opening the door starts a 30 second entry delay and the Control Station emits a buzz tone to remind you to disarm the system. Enter your personal combination *before* the entry time expires and the system disarms. If you enter through a wrong door or fail to disarm the system before the entry delay expires, you will generate an immediate alarm.

## Silencing the Alarm

Your alarm audible has a specific period of time that it sounds before it automatically shuts off. If an alarm occurs and you want to silence the alarm, simply enter your personal combination and the siren shuts off.

**IMPORTANT:** Some security systems do not permit the Model 259 Control Station to silence the alarm. The alarm must be silenced from a different control station in your system.

- My system can be silenced from the Model 259 Control Station.
- My system must be silenced from the control station located \_\_\_\_\_

## Panic Alert (Optional)

The panic alert is available 24 hours a day and is used to generate an instant alarm signal. The alarm may be silent or it may be an audible response, depending on programming. The panic alert is initiated by pressing the two \* keys on the Model 259 at the same time. Some systems are not programmed for this feature. Your alarm technician will check the appropriate box below to indicate how your system is programmed.

- My system has a panic alarm feature.
- My system does not have a panic alarm feature.